

Scag 48089

Where Used List

Models:

MAG III (70000-79999) 72"
SW-13BV (1001-1150)
SW-13KH (1001-1400)
SW-14KA (60001-69999)
SW-14KA (70000-79999)
SW-14KA-10000
SW-14KA-40000
SW-14KA-50001
SW-14KH-10000
SW-14KH-40000
SW-14KH-50001
SW-16BV (60001-69999)
SW-16BV (70000-79999)
SW-16BV (S/N 3200001-3209999)
SW-16BV-40000
SW-16BV-50001
SW-16BVE-50001
SW-18BV (60001-69999)
SW-18BV (70000-79999)
SW-18BV (S/N 3210001-3219999)
SW-18BV-40000
SW-18BV-50001
SW-18CVE (60001-69999)
SW-18CVE (70000-79999)
SW-18CVE-40000
SW-18CVE-50001
SW-18EKH (1001-UP)
SW-18KH (METAL TANKS, NO OPERATOR CONTROLS)
SW-18KH-10000
SW-18KH-1801
SW-20EKH (1001-UP)
SW-20KHE-10000
SW-48V-14FS Walk-Behind (S/N S2500001-S2599999) Part No. 06362
SW32-12B (METAL TANKS, NO OPERATOR CONTROLS)

SW32-12B (PLASTIC TANKS, OPERATOR CONTROLS)
SW32-13BV (1001-1116)
SW32-13KA (S/N 3110001-3119999)
SW32-13KA-40000
SW32-13KA-50001
SW36-12B (METAL TANKS, NO OPERATOR CONTROLS)
SW36-12B (PLASTIC TANKS, OPERATOR CONTROLS)
SW36-12BS (PLASTIC TANKS, OPERATOR CONTROLS)
SW36-13BV (1001-1393)
SW36-13K (METAL TANKS, NO OPERATOR CONTROLS)
SW36-13K (PLASTIC TANKS, OPERATOR CONTROLS)
SW36-13KA (40000-49999)
SW36-13KA (4522-UP)
SW36-13KA (50000-59999)
SW36-13KA (S/N 3120001-3129999)
SW36-13KA-10000
SW36-13KH (1001-UP)
SW36-13KH (40000-49999)
SW36-13KH (50000-59999)
SW36-13KH (S/N 3130001-3139999)
SW36-13KH-10000
SW36-8J (METAL TANKS, NO OPERATOR CONTROLS)
SW36-8J (OPERATOR CONTROLS, 4 & 5 SPEED TRANSMISSIONS)
SW36-8J (PLASTIC TANKS, OPERATOR CONTROLS)
SW48-12B (METAL TANKS, NO OPERATOR CONTROLS)
SW48-12B (PLASTIC TANKS, OPERATOR CONTROLS)
SW48-13BV (1001-1402)
SW48-13K (METAL TANKS, NO OPERATOR CONTROLS)
SW48-13K (PLASTIC TANKS, OPERATOR CONTROLS)
SW48-13KA (1001-5291)
SW48-13KH (1001-2200)
SW48-14KA (60001-69999)
SW48-14KA (70000-79999)
SW48-14KA (S/N 3140001-3149999)
SW48-14KA (S/N 4000001-4009999)
SW48-14KA-10000
SW48-14KA-40000
SW48-14KA-50001
SW48-14KAE (60001-69999)
SW48-14KAE (70000-79999)
SW48-14KAE (S/N 3160001-3169999)
SW48-14KAE-50001
SW48-14KH (60001-69999)

SW48-14KH (70000-79999)
SW48-14KH (S/N 3150001-3159999)
SW48-14KH-10000
SW48-14KH-40000
SW48-14KH-50001
SW48-15KH (S/N 4010001-4019999)
SW48-16BV (60001-69999)
SW48-16BV (70000-79999)
SW48-16BV (S/N 3170001-3179999)
SW48-17KA (S/N 3180001-3189999)
SW48-17KA (S/N 4020001-4029999)
SW48A-14KA (S/N 7090001-7099999)
SW48A-15KA (S/N 7340001-7349999)
SW48A-15KA (S/N 8060001-8069999)
SW48A-15KA (S/N 8950001-8959999)
SW48A-15KA (S/N A0500001-A0599999)
SW48A-15KH (S/N 7100001-7109999)
SW48A-15KH (S/N 8070001-8079999)
SW48A-15KH (S/N 8960001-8969999)
SW48A-15KH (S/N A0600001-A0699999)
SW48A-17KA (S/N 6170001-6179999)
SW48A-17KA (S/N 7350001-7359999)
SW48A-17KA (S/N 8080001-8089999)
SW48A-17KA (S/N 8980001-8989999)
SW48A-17KA (S/N A0800001-A0899999)
SW48A-18HN (S/N 9610001-9619999)
SW48V-14FS (S/N J6200001-J6299999)
SW48V-14FS (S/N N4300001-N4399999) Part No.6315
SW48V-14FS Walk-Behind (S/N K8800001-K8899999)
SW48V-14FS Walk-Behind (S/N N4300001-N4399999) Part No. 06315
Rev.1
SW48V-15KA Walk Behind (S/N B1300001-B1399999)
SW48V-15KH (S/N D6000001-D6099999)
SW48V-15KH Walk Behind (S/N B1400001-B1499999)
SW48V-15KH Walk Behind (S/N C3300001-C3399999)
SW48V-16FS (S/N F1500001-F1599999)
SW48V-16KAI (S/N D6100001-D6199999)
SW48V-16KAI Walk Behind (S/N C0600001-C0699999)
SW48V-16KAI Walk Behind (S/N C3400001-C3499999)
SW48V-17KAI Walk Behind (S/N C0700001-C0799999)
SW48V-481FS (S/N F9800001-F9899999)
SW48V-481FS (S/N H2500001-H2599999)
SW52-13K (METAL TANKS, NO OPERATOR CONTROLS)

SW52-13K (PLASTIC TANKS, OPERATOR CONTROLS)
SW52-18KH (PLASTIC TANKS, OPERATOR CONTROLS)
SW52V-15FS (S/N J6300001-J6399999)
SW52V-15FS Walk-Behind (S/N K8900001-K8999999)
SW52V-17KAI (S/N D6200001-D6299999)
SW52V-18FS (S/N F1600001-F1699999)
SW52V-541FS (S/N F1600001-F1699999)
SW52V-541FS (S/N H2600001-H2699999)
SW61-18KH (PLASTIC TANKS, OPERATOR CONTROLS)
SWM-52V (S/N D5400001-D5499999)
SWZ (60001-69999)
SWZ-14KA (1001-UP)
SWZ-14KA (3300001-3309999)
SWZ-14KA (40000-49999)
SWZ-14KA (50000-59999)
SWZ-14KA-10000
SWZ-14KH (1001-UP)
SWZ-14KH (40000-49999)
SWZ-14KH (50000-59999)
SWZ-14KH-10000
SWZ-16BV (3310001-3319999)
SWZ-16BV (70000-79999)
SWZ-16BV-40000
SWZ-16BV-50001
SWZ-16BVE (3320001-3329999)
SWZ-16BVE (70000-79999)
SWZ-16BVE-50001
SWZ-17KA (S/N 9150001-9159999)
SWZ-18BV (3330001-3339999)
SWZ-18BV (70000-79999)
SWZ-18BV-40000
SWZ-18BV-50001
SWZ-18KH (1001-UP)
SWZ-18KH-10000
SWZ-20CVE (3340001-3349999)
SWZ-20CVE (70000-79999)
SWZ-20CVE-40000
SWZ-20CVE-50001
SWZ-20KHE (1001-UP)
SWZ-20KHE-10000
SWZ-21KAE (S/N 9160001-9169999)
SWZ-48V-15FSE Walk-Behind (S2800001-S2899999) Part No. 06363
SWZ32-13KA-40000

SWZ36-14KA (1001-2000)
SWZ36-14KA-10000
SWZ36-14KA-40000
SWZ36-14KA-50001
SWZ36-14KH (1001-2000)
SWZ36-14KH-10000
SWZ36-14KH-40000
SWZ36-14KH-50001
SWZ36A-16FS-LE (S/N F1800001-F1899999)
SWZ48-14KA (1001-2000)
SWZ48-14KA (3250001-3259999)
SWZ48-14KA (4060001-4069999)
SWZ48-14KA (70000-79999)
SWZ48-14KA (S/N 5140001-5149999)
SWZ48-14KA-10000
SWZ48-14KA-40000
SWZ48-14KA-50001
SWZ48-14KAE (3270001-3279999)
SWZ48-14KAE (70000-79999)
SWZ48-14KAE-50001
SWZ48-14KH (1001-2000)
SWZ48-14KH (3260001-3269999)
SWZ48-14KH (70000-79999)
SWZ48-14KH-10000
SWZ48-14KH-40000
SWZ48-14KH-50001
SWZ48-15KH (4070001-4079999)
SWZ48-15KH (S/N 5150001-5159999)
SWZ48-16BV (3280001-3289999)
SWZ48-17KA (3290001-3299999)
SWZ48-17KA (4080001-4089999)
SWZ48-17KA (S/N 5160001-5169999)
SWZ48A-17KA (S/N 5170001-5179999)
SWZ48A-17KA (S/N 6260001-6269999)
SWZ48A-17KA (S/N 7380001-7389999)
SWZ48A-17KA (S/N 8120001-8129999)
SWZ48A-17KA (S/N 9040001-9049999)
SWZ48A-17KA (S/N A1600001-A1699999)
SWZ48A-17KAE (S/N 8130001-8139999)
SWZ48A-17KAE (S/N 9050001-9059999)
SWZ48A-17KAE (S/N A1700001-A1799999)
SWZ48A-18HN (S/N 9620001-9629999)
SWZ48A-18HN (S/N A1800001-A1899999)

SWZ48V-15FS (S/N J6500001-J6599999)
SWZ48V-15FS (S/N N4600001-N4699999) Part No.06316
SWZ48V-15FS Walk-Behind (S/N K9100001-K9199999)
SWZ48V-17KAI (S/N D4600001-D4699999)
SWZ48V-17KAI Walk Behind (S/N C1000001-C1099999)
SWZ48V-17KAI Walk Behind (S/N C3800001-C3899999)
SWZ48V-17KAIE Walk Behind (S/N C1100001- C1199999)
SWZ48V-18FS (S/N F1900001-F1999999)
SWZ48V-18FS-LE (S/N F2000001-F2099999)
SWZ48V-18HN Walk Behind (S/N B2200001-B2299999)
SWZ48V-541FS (S/N G0100001-G0199999)
SWZ48V-541FS (S/N H2800001-H2899999)
SWZ52V-17KAI (S/N D4700001-D4799999)
SWZ52V-18FS (S/N J6600001-J6699999)
SWZ52V-18FS Walk-Behind (S/N K9200001-K9299999)
SWZ52V-19KAI (S/N D4800001-D4899999)
SWZ52V-20FS (S/N F2100001-F2199999)
SWZ52V-600FS (S/N G0200001-G0299999)
SWZ52V-600FS (S/N H2900001-H2999999)
SWZL52V-18FS Walk-Behind (S/N M1600001-M1699999)
SWZL52V-22FSE (S/N N5200001-N5299999) Part No.06316