

Scag 481707

Where Used List

Models:

SFW36-16BV (S/N E5600001-E5699999)

SFW36-16BV (S/N F9100001-F9199999)

SMTC-52A (S/N 6660000-6669999)

STC52A-21KA (S/N 6610000-6619999)

STC52A-23KA (S/N 6620000-6629999)

STC52A-23LV (S/N 6630000-6639999)

STT52-22KA (S/N 5460001-5469999)

STT52-23CH (S/N 5380001-5389999)

STT52-25CH (S/N 5420001-5429999)

STT52A-22KA (S/N 5480001-5489999)

STT52A-22KA (S/N 6740001-6749999)

STT52A-23CH (S/N 5400001-5409999)

STT52A-23CH (S/N 6670001-6679999)

STT52A-23KA (S/N 7200001-7209999)

STT52A-25CH (S/N 5440001-5449999)

STT52A-25CH (S/N 6700001-6709999)

SW-36A-14FS Walk-Behind (S/N S2400001-S2499999) Part No.
06362

SW-52V-15FS Walk-Behind (S/N S2600001-S2699999) Part No.
06362

SW32-14FS (S/N J6000001-J6099999)

SW32-14FS Walk-Behind (S/N J6000001-J6099999)

SW32-14FS Walk-Behind (S/N L2000001-L2099999)

SW32-15KAI (S/N D5700001-D5799999)

SW32-16FS (S/N F1200001-F1299999)

SW32-481FS (S/N F9500001-F9599999)

SW32-481FS (S/N H2200001-H2299999)

SW36A-13KA (S/N 7070001-7079999)

SW36A-13KH (S/N 7080001-7089999)

SW36A-13KH (S/N 8920001-8929999)

SW36A-14FS (S/N J6100001-J6199999)

SW36A-14FS (S/N N4200001-N4299999) Part No.6315

SW36A-14FS Walk-Behind (S/N J6100001-J6199999)

SW36A-14FS Walk-Behind (S/N L2100001-L2199999)

SW36A-14FS Walk-Behind (S/N N4200001-N4299999) Part No.
06315 Rev.1

SW36A-14KA (S/N 6140001-6149999)

SW36A-15KA (S/N 8930001-8939999)

SW36A-15KA (S/N A0300001-A0399999)

SW36A-15KH (S/N 8940001-8949999)

SW36A-15KH (S/N A0400001-A0499999)

SW36A-15KH (S/N D5800001-D5899999)
SW36A-15KH Walk Behind (S/N B1200001-B1299999)
SW36A-15KH Walk Behind (S/N C3100001-C3199999)
SW36A-16FS (S/N F1300001-F1399999)
SW36A-16FS-LE (S/N F1400001-F1499999)
SW36A-16KAI (S/N D5900001-D5999999)
SW36A-16KAI Walk Behind (S/N C0500001-C0599999)
SW36A-16KAI Walk Behind (S/N C3200001-C3299999)
SW36A-17KAI (S/N E5900001-E5999999)
SW36A-481FS (S/N F9700001-F9799999)
SW36A-481FS (S/N H2400001-H2499999)
SW48V-14FS (S/N J6200001-J6299999)
SW48V-14FS Walk-Behind (S/N K8800001-K8899999)
SW48V-15KH (S/N D6000001-D6099999)
SW48V-16FS (S/N F1500001-F1599999)
SW48V-16KAI (S/N D6100001-D6199999)
SW48V-481FS (S/N F9800001-F9899999)
SW48V-481FS (S/N H2500001-H2599999)
SW52A-17KA (S/N 7110001-7119999)
SW52A-17KA (S/N 8990001-8999999)
SW52A-17KA (S/N A1000001-A1099999)
SW52A-18HN (S/N 9000001-9009999)

SW52A-18HN (S/N A1100001-A1199999)

SW52A-18KH (S/N 9010001-9019999)

SW52A-18KH (S/N A1200001-A1299999)

SW52V-15FS (S/N J6300001-J6399999)

SW52V-15FS (S/N N4400001-N4499999) Part No.6315

SW52V-15FS Walk-Behind (S/N K8900001-K8999999)

SW52V-15FS Walk-Behind (S/N N4400001-N4499999) Part No.
06315 Rev.1

SW52V-17KAI (S/N D6200001-D6299999)

SW52V-17KAI Walk Behind (S/N C0800001-C0899999)

SW52V-17KAI Walk Behind (S/N C3500001-C3599999)

SW52V-18FS (S/N F1600001-F1699999)

SW52V-18HN Walk Behind (S/N B1700001-B1799999)

SW52V-18KH Walk Behind (S/N B1800001-B1899999)

SW52V-18KH Walk Behind (S/N C3600001-C3699999)

SW52V-541FS (S/N F1600001-F1699999)

SW52V-541FS (S/N H2600001-H2699999)

SWM-52A (S/N 6320001-6329999)

SWM-52A (S/N 9170001-9179999)

SWM-52A (S/N A3400001-A3499999)

SWM-52V (S/N D5400001-D5499999)

SWM-52V Walk Behind (S/N B3400001-B3499999)

SWM-52V Walk Behind (S/N C5100001-C5199999)
SWMU-52A (S/N 6380001-6389999)
SWMU-52A (S/N 8250001-8259999)
SWMU-52A (S/N 9200001-9209999)
SWMU-52A (S/N A3700001-A3799999)
SWU36A-15KA (S/N 6190001-6199999)
SWU48A-17KA (S/N 6200001-6209999)
SWU52A-17KA (S/N 6210001-6219999)
SWZ-17KA (S/N 9150001-9159999)
SWZ-20FS (S/N F2400001-F2499999)
SWZ-21KAE (S/N 9160001-9169999)
SWZ-22FSE (S/N F2500001-F2599999)
SWZ-36A-14FS Walk-Behind (S2700001-S2799999) Part No. 06363
SWZ-52V-18FSE Walk-Behind (S2900001-S2999999) Part No. 06363
SWZ-600FS (S/N G0500001-G0599999)
SWZ-651FSE (S/N G0600001-G0699999)
SWZ36-14KA (S/N 5120001-5139999)
SWZ36-15KH (S/N 5130001-5139999)
SWZ36A-14FS (S/N J6400001-J6499999)
SWZ36A-14FS (S/N N4500001-N4599999) Part No.06316
SWZ36A-14FS Walk-Behind (S/N K9000001-K9099999)
SWZ36A-14FS Walk-Behind (S/N L2400001-L2499999)

SWZ36A-14KA (S/N 6230001-6239999)
SWZ36A-15KA (S/N 7190001-7199999)
SWZ36A-15KA (S/N 9020001-9029999)
SWZ36A-15KA (S/N A1400001-A1499999)
SWZ36A-15KA Walk Behind (S/N B1900001-B1999999)
SWZ36A-16FS (S/N F1700001-F1799999)
SWZ36A-16FS-LE (S/N F1800001-F1899999)
SWZ36A-16KAI (S/N D4500001-D4599999)
SWZ36A-16KAI Walk Behind (S/N C0900001-C0999999)
SWZ36A-16KAI Walk Behind (S/N C3700001-C3799999)
SWZ36A-17KAI (S/N E6100001-E6199999)
SWZ36A-481FS (S/N G0000001-G0099999)
SWZ36A-481FS (S/N H2700001-H2799999)
SWZ48V-15FS (S/N J6500001-J6599999)
SWZ48V-15FS Walk-Behind (S/N K9100001-K9199999)
SWZ48V-17KAI (S/N D4600001-D4699999)
SWZ48V-18FS (S/N F1900001-F1999999)
SWZ48V-18FS-LE (S/N F2000001-F2099999)
SWZ48V-541FS (S/N G0100001-G0199999)
SWZ48V-541FS (S/N H2800001-H2899999)
SWZ52A-17KA (S/N 6280001-6289999)
SWZ52A-17KA (S/N 9060001-9069999)

SWZ52A-17KA (S/N A1900001-A1999999)
SWZ52A-18HN (S/N 9070001-9079999)
SWZ52A-18HN (S/N A2000001-A2099999)
SWZ52A-18KH (S/N 9080001-9089999)
SWZ52A-18KH (S/N A2100001-A2199999)
SWZ52A-19KAI (S/N A2200001-A2299999)
SWZ52V-17KAI (S/N D4700001-D4799999)
SWZ52V-17KAI Walk Behind (S/N C1200001-C1299999)
SWZ52V-17KAI Walk Behind (S/N C3900001-C3999999)
SWZ52V-18FS (S/N J6600001-J6699999)
SWZ52V-18FS (S/N N4700001-N4799999) Part No.06316
SWZ52V-18FS Walk-Behind (S/N K9200001-K9299999)
SWZ52V-18HN Walk Behind (S/N B2400001-B2499999)
SWZ52V-18KH Walk Behind (S/N B2500001-B2599999)
SWZ52V-18KH Walk Behind (S/N C4000001-C4099999)
SWZ52V-19KAI (S/N D4800001-D4899999)
SWZ52V-19KAI Walk Behind (S/N B2600001-B2699999)
SWZ52V-19KAI Walk Behind (S/N C4100001-C4199999)
SWZ52V-20FS (S/N F2100001-F2199999)
SWZ52V-600FS (S/N G0200001-G0299999)
SWZ52V-600FS (S/N H2900001-H2999999)

SWZL-52V-22FSE Walk-Behind (S3300001-S3399999) Part No.
06363

SWZL52V-18FS (S/N N5100001-N5199999) Part No.06316

SWZL52V-18FS Walk-Behind (S/N M1600001-M1699999)

SWZL52V-22FSE (S/N N5200001-N5299999) Part No.06316

SWZU36-15KA (S/N 5260001-5269999)

SWZU36A-15KA (S/N 6340001-6349999)

SWZU36A-15KA (S/N 8160001-8169999)

SWZU36A-15KA (S/N 9090001-9099999)

SWZU36A-15KA (S/N A2300001-A2399999)

SWZU36A-16KAI Walk Behind (S/N C1300001-C1399999)

SWZU36A-16KAI Walk Behind (S/N C4200001-C4299999)

SWZU52-17KA (S/N 5280001-5289999)

SWZU52A-17KA (S/N 6360001-6369999)

SWZU52A-17KA (S/N 8180001-8189999)

SWZU52A-17KA (S/N 9120001-9129999)

SWZU52A-17KA (S/N A2700001-A2799999)

SWZU52A-18HN (S/N 9130001-9139999)

SWZU52A-18HN (S/N A2800001-A2899999)

SWZU52A-18KH (S/N 8190001-8199999)

SWZU52A-18KH (S/N 9140001-9149999)

SWZU52A-18KH (S/N A2900001-A2999999)

SWZU52A-19KAI (S/N A3000001-A3099999)

SWZU52V-17KAI Walk Behind (S/N C1500001-C1599999)

SWZU52V-17KAI Walk Behind (S/N C4400001-C4499999)

SWZU52V-19KAI (S/N D4400001-D4499999)

SWZU52V-19KAI Walk Behind (S/N B3000001-B3099999)

SWZU52V-19KAI Walk Behind (S/N B4500001-B4599999)

SWZV36A-16KAI (Pro V) (S/N D4000001-D4099999)

SWZV52V-19KAI (Pro V) (S/N D4200001-D4299999)

SWZV52V-23KAE (Pro V) (S/N E2700001-E2799999)