

# Scag 481708

## Where Used List

**Models:**

SM-61 (S/N 5350001-5359999)	Cutter Deck - 61
SM-61A (S/N 5370001-5379999)	Cutter Deck - 61
SM-61A (S/N 6410001-6419999)	Cutter Deck 61"
SM-61E (S/N 5350001-5359999)	Cutter Deck - 61
SMWC-61A Wildcat (S/N 9340001-9349999)	61A Cutter Deck
STHM-23CV (S/N 5340001-5349999)	Cutter Deck - 61
STHM-23CV (S/N 640001-6409999)	Cutter Deck 61"
STT61-22KA (S/N 5470001-5479999)	Cutter Deck
STT61-23CH (S/N 5390001-5399999)	Cutter Deck
STT61-25CH (S/N 5430001-5439999)	Cutter Deck
STT61A-22KA (S/N 5490001-5499999)	Cutter Deck
STT61A-22KA (S/N 6750001-6759999)	52A & 61A Cutter Decks
STT61A-23CH (S/N 5410001-5419999)	Cutter Deck
STT61A-23CH (S/N 6680001-6689999)	52A & 61A Cutter Decks

STT61A-23KA (S/N 7210001-7219999)	52A & 61A Cutter Decks
STT61A-25CH (S/N 5450001-5459999)	Cutter Deck
STT61A-25CH (S/N 6710001-6719999)	52A & 61A Cutter Decks
STT61A-27KA (S/N 6760001-6769999)	52A & 61A Cutter Decks
STWC61A-27CV Wildcat (S/N 9660001-9669999)	61A Cutter Deck
SWM-61A (S/N 9180001-9189999)	Cutter Decks 61A
SWM-61A (S/N A3500001-A3599999)	Cutter Decks 61A
SWM-61V (S/N D5500001-D5599999)	61V Cutter Deck
SWM-61V Walk Behind (S/N B3500001-B3599999)	Cutter Decks
SWM-61V Walk Behind (S/N C5200001-C5299999)	Cutter Decks 61V
SWMU-61A (S/N 6390001-6399999)	61" A Cutter Decks
SWMU-61A (S/N 8260001-8269999)	Cutter Deck 61A
SWMU-61A (S/N 9210001-9219999)	Cutter Decks 61"
SWMU-61A (S/N A3800001-A3899999)	Cutter Decks 61" A
SWZ-17KA (S/N 6290001-6299999)	61A" Cutter Deck
SWZ-17KA (S/N 9150001-9159999)	Cutter Decks 61A

SWZ-18FS (S/N J7000001-J7099999)	61V Cutter Deck
SWZ-18FS Walk-Behind (S/N K9600001-K9699999)	61V Cutter Deck
SWZ-20FS (S/N F2400001-F2499999)	61V Cutter Deck
SWZ-21KAE (S/N 6300001-6309999)	61A" Cutter Deck
SWZ-21KAE (S/N 9160001-9169999)	Cutter Decks 61A
SWZ-22FSE (S/N F2500001-F2599999)	61V Cutter Deck
SWZ-22FSE (S/N J7100001-J7199999)	61V Cutter Deck
SWZ-22FSE Walk-Behind (S/N K9700001-K9799999)	61V Cutter Deck
SWZ-600FS (S/N G0500001-G0599999)	61V Cutter Deck
SWZ-600FS (S/N H3300001-H3399999)	61V Cutter Deck
SWZ-651FSE (S/N G0600001-G0699999)	61V Cutter Deck
SWZ-651FSE (S/N H3400001-H3499999)	61V Cutter Deck
SWZ36A-14FS (S/N J6400001-J6499999)	61V Cutter Deck
SWZ36A-14FS Walk-Behind (S/N K9000001-K9099999)	61V Cutter Deck
SWZ36A-16FS (S/N F1700001-F1799999)	61V Cutter Deck
SWZ36A-16FS-LE (S/N F1800001-F1899999)	61V Cutter Deck

SWZ36A-481FS (S/N H2700001-H2799999)	61V Cutter Deck
SWZ48V-15FS (S/N J6500001-J6599999)	61V Cutter Deck
SWZ48V-18FS (S/N F1900001-F1999999)	61V Cutter Deck
SWZ48V-18FS-LE (S/N F2000001-F2099999)	61V Cutter Deck
SWZ48V-541FS (S/N H2800001-H2899999)	61V Cutter Deck
SWZ52V-18FS (S/N J6600001-J6699999)	61V Cutter Deck
SWZ52V-20FS (S/N F2100001-F2199999)	61V Cutter Deck
SWZ52V-600FS (S/N H2900001-H2999999)	61V Cutter Deck
SWZL-61V-22FSE Walk-Behind (S3400001-S3499999) Part No. 06363	61V CUTTER DECK
SWZL61V-22FSE (S/N N5300001-N5399999) Part No.06316	61V CUTTER DECK
SWZL61V-22FSE Walk-Behind (S/N M1800001-M1899999)	61V Cutter Deck